

## **ERECTOR NOTE!**

**USE 1-HIGH STRENGTH WASHER OVER ALL** SLOTS IN CONNECTION ANGLES FOR ALL BEAM TO BEAM AND BEAM TO COLUMN

